

1.14 Limits

The *tolerance set* is

$$\mathbb{E} = \{10^{-1}, 10^{-2}, \dots\}.$$

For $n \in \mathbb{Z}_{>0}$ define $d: \mathbb{R}^n \times \mathbb{R}^n \rightarrow \mathbb{R}_{\geq 0}$

$$d(x, y) = \sqrt{(y_1 - x_1)^2 + \dots + (y_n - x_n)^2}, \quad \text{if } x = (x_1, \dots, x_n) \text{ and } y = (y_1, \dots, y_n).$$

Let $m, n \in \mathbb{Z}_{>0}$ and let $f: \mathbb{R}^m \rightarrow \mathbb{R}^n$. Let $a \in \mathbb{R}^m$ and $\ell \in \mathbb{R}^n$.

$$\lim_{x \rightarrow a} f(x) = \ell \quad \text{means}$$

if $\varepsilon \in \mathbb{E}$ then there exists $\delta \in \mathbb{E}$ such that if $0 < d(x, a) < \delta$ then $d(f(x), \ell) < \varepsilon$.

Here is a translation into the language of “English”:

In English

The client has a machine f
that produces steel rods of length ℓ for sales.

The output of f gets closer and closer to ℓ
as the input gets closer and closer to a
means

if you give me a tolerance the client needs,
in other words,
the number of decimal places of accuracy
the client requires

then my business will tell you

the accuracy you need on the dials of the machine
so that

if the dials are set within δ of a

then the output of the machine
will be within ε of ℓ .

In Math

Let $f: X \rightarrow \mathbb{R}$ and let $\ell \in \mathbb{R}$.

$\lim_{x \rightarrow a} f(x) = \ell$ means

if $\varepsilon \in \mathbb{E}$

then there exists

$\delta \in \mathbb{E}$ such that

if $0 < d(x, a) < \delta$

then $d(f(x), \ell) < \varepsilon$.

Let $n \in \mathbb{Z}_{>0}$ and let a_1, a_2, \dots be a sequence in \mathbb{R}^n . Let $\ell \in \mathbb{R}$.

$$\lim_{n \rightarrow \infty} a_n = \ell \quad \text{means}$$

if $\varepsilon \in \mathbb{E}$ then there exists $N \in \mathbb{Z}_{>0}$ such that if $n \in \mathbb{Z}_{\geq N}$ then $d(a_n, \ell) < \varepsilon$.